Delay ON star/delta time relay JART8-ST **Instruction Manual**






General

- Applications
 - -Designated for delay ON of motors star/delta.
- Function Features
 - -Time t1 (star):

time scale 0.1 s - 10min devided into 4 time ranges rough time setting by rotary switch.

- -Time t2 (delay):
 - time scale 0.1 s 1 s


- time seate 0.1 s 1 s time setting by potentiometer Relay status is indicated by LED. 1-MODULE,DIN rail mounting.
- Model and connotation



Technical parameters

Technical parameters	JART8-ST
Function	Delay ON star/delta
Supply terminals	A1-A2
Voltage range	AC/DC 12-240V(50-60Hz)
Burden	AC 0.3-2VA/DC 0.1-1.2W
Supply voltage tolerance	-15%;+10%
Supply indication	green LED
Time ranges	Range of time delay t1: 0.1 s - 10 min, Switch time t2: 0.1 s-1 s
Time setting	potentionmeter
Time deviation	10%-mechanical setting
Repeat accuracy	0.2%-set value stability
Temperature coecient	0.05%/°C,at=20°C($0.05%$ °F, at=68°F)
Output	2× SPDT
Current rating	16A/AC1
Switching voltage	250VAC/24VDC
Min.breaking capacity DC	500mW
Output indication	red LED
Mechanical life	1× 10 ⁷
Electrical life(AC1)	1× 10 ⁵
Reset time	max.200ms
Operating temperature	-20°C to +55°C (-4°F to 131°F)
Storage temperature	-35°C to +75°C (-22°F to 158°F)
Mounting/DIN rail	Din rail EN/IEC 60715
Protection degree	IP40 for front panel/IP20 terminals
Operating position	any
Overvoltage cathegory	III.
Pollution degree	2
Max.cable size(mm²)	solid wire max.1 \times 2. 5or 2 \times 1. 5/ with sleeve max.1 \times 2. 5(AWG 12)
Tightening torque	0.4Nm
Dimensions	90× 18× 64mm
Weight	82g
Standards	EN 61812-1,IEC60947-5-1

Panel Diagram



Functions Diagram

Delay ON star / delta



Setting instructions



Knob 1: delay gear setting, "s" for second, "m" for minute.




Knob 2: fine adjustment of delay time, 10% ~ 100% adjustable.


Delay time = $knob 1 \times knob 2$.

Example 1: it needs to be set for 5 seconds. You can set knob 1 to 10s, knob 2 to 50%, and delay time = $10s \times 50\% = 5s$.


Example 2: it needs to be set for 8 minutes. You can set knob 1 to 10m, knob 2 to 80%, and delay time = $10m \times 80\% = 8m$.

Wiring Diagram





Dimensions(mm)





Disposal of Electrical WasteAll electrical waste should be disposed of in compliance with current WEEE regulations.



Caution

The products must be installed by qualified electricians. All and any electrical connections of the product shall comply with the appropriate safety standards.